
## TORONTO WALL UNIT




1 - 8 2012-12-13

DO NOT USE POWER TOOLS DURING ASSEMBLY AS IT MAY DAMAGE THE PRODUCT, AND WARRANTY WILL BE VOIDED.

PLEASE CHECK THAT THE COMPONENTS AND FITTINGS
ARE COMPLETE AND THE QUANTITIES ARE CORRECT
BEFORE ASSEMBLY. SHOULD THERE BE MISSING OR
DAMAGED FITTINGS AND COMPONENTS, DO NOT
ASSEMBLE THE PRODUCT. CONTACT THE SUPPLIER
IMMEDIATELY.

FOR THE PRODUCT TO FUNCTION PROPERLY, IT IS
RECOMMENDED THAT ALL BOLTS, NUTS AND SCREWS BE
TIGHTENED PERIODICALLY(EVERY 2-3 MONTHS). PLEASE
DO NOT OVER TIGHTEN TO AVOID DAMAGING THE
PRODUCT.


## **ASSEMBLY TOOLS REQUIRED**




Philip Head Screw Driver


**NOT INCLUDED** 





C





Α	2	900 x 290 x 34 mm	
В	2	1730 x 288 x 34 mm	
С	1	1730 x 112 x 15 mm	
D	4	470 x 270 x 34 mm	
Е	4	470 x 270 x 34 mm	

(F) WOOD DOWEL	(G) M5 X 38 SCREW	(H) M4 X 65 SCREW	(I) METAL DOWEL	(J) LOCKING NUT	( K ) 15 MM CAP	(L) NAIL LEG
	(%)	(%) <u></u>				
36 PCS	16 PCS	10 PCS	16 PCS	16 PCS	16 PCS	6 PCS

( M ) ANCHOR PLUG Ø7.5 X 30mm	( N ) PLASTIC PLATE 84MM	( O ) M3.5 X 16 SCREW	(P) M4 X 32 Screw
	0 0 0 0	(%)))))))>	(%) 
1 PC	1 PC	2 PCS	1 PC

